

MT Box Nokia unlock BB5 without test point short user manual

- Download and install MTB NK setup 1.54.exe software (or higher if any)
- Connect your MT box to USB
- Go to C:\Program Files\GriffinTeam\MT-Box\ and start MT box update tool v3.7 (do not use older version because will not work)
- Press info button to see it is communication ok
- Press UPDATE button and wait to software finish
- After successful activation log as bellow appears:

Device:<\\?\usb#vid_***0&pid_f00d#00xxxxxxxx#{e6ef 7dcd-1795-4a08-9fbf-aa78423c26f0}>

SN:00xxxxxxxx

Getting BOX Status...OK

Getting INI File Update....[PIN:74xxxxxBFB3xxxxx]OK

SN:00xxxxxxxx

Server Login... OK

Ask...OK

Server I/O....OK

Updating...BOX is Updated!

- Update of box you need to do only first time
- Your box is ready for unlock BB5 without TP
- Close MT box update tool v3.7
- Start MTB NK 1.54 exe or higher
- Connect phone to box FBUS cable
- Phone need to be in LOCAL mode
- Press phone info button
- Press UNLOCK button